





As per above picture①:Unscrew the push button nut.Install the push button to the hole of tank lid and tighten the nut(Picture③).