


Coordinated Bathrooms Designed For You

Installation & Maintenance Instructions



AERO ELECTRIC TOWEL RADIATOR 640

CONTENTS

Dimension	02
Spare Parts	03
Technical Specification	04
Installation Steps	05
Replacement of control panel	07
The guide of the control panel	08
Stand-by mode	08
Power-on mode	08
Adjust Temperature	09
Test	09
Troubleshoot	10
Maintenance & Cleaning	10

Important

The product is designed for household or residential use. You are advised to have the product installed by an authorized professional installer. Make sure the product is properly connected to 230V and is earthed.

WARNING: This device is not designed to bear the weight of a person, and no one should therefore climb onto it.

This appliance can be used by children aged from 8 years and above and persons with reduced physical sensory or mental capabilities or lack of experience and knowledge if they are supervised or have been given instruction concerning use of the appliance in a safe way and understand the hazards involved. Children should not play with the appliance.

Cleaning and user maintenance should not be carried out by children without supervision. Children must be supervised at all times to ensure that they do not interfere with the product.









WARNING:

The product must never be installed its control panel at the below. This product must not be installed horizontally.


Dimension



Spare Parts




Technical Specification





Frequence	50Hz	
Rated power	80W	
Votage	AC230V	
Heating time	5-10min	
Heating temperature	45-60°C	
Ingress protection	IP4	
Heating method	Dry heating	

Installation Steps




Replacement of control panel





The guide of the control panel

SHE	Screen
(1)	Ajust Temperature
0	Timer
(6)	On/Off



Switch on & off

After connecting the power supply, and the beep sounds into the stand-by mode.

In stand-by mode, press and the **4** button for 5 seconds to change Celsius or Fahrenheit (factory default is Celsius), the buzzer will ring when the setting is successful.

To switch the product on, please press the button for one second. To switch the product off, please press the button for one second again.

Timer

With the power on, please press the button to set the timing. Available Timing: 1H-2H-3H-4H-5H-6H-7H-8H.

Adjust Temperature

With the power on, please press the 4 button to set the temperature.

Available Temperature:45 °C (115 °F) , 50 °C (125 °F) ,55 °C (135 °F) ,60 °C (145 °F)

With the power on, Press the 4 button for one second to switch to: real-time temperature/timed time alternating display.

Test

When an abnormality occurs in the circuit, the chip automatically detects it and displays it on the screen, while the circuit carries out automatic protection to force the radiator to be off.

Troubleshoot

-Please troubleshoot according to the display on the screen.

E1	Temperature sensor open-circuit.
E2	Temperature sensor short-circuit
E3	Overtemperature protection
E0	Leakage protection

Maintenance & Cleaning

The product does not require any type of maintenance. We recommend that all parts of the product are kept clean (behind, underneath, upper fins, etc.). Do not use any abrasive product on the steel main body. Clean it with a damp cloth and a pH neutral soap, and the control panel with a dry cloth.

















